

TWIN SPOTLIGHT MODEL #FL1
INSTALLTION INSTRUCTION SHEET

READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION.

WIRING THE UNIT INCORRECTLY MAY DAMAGE THE ELECTRONIC COMPONENTS INSIDE THE CONTROL MODULE CAUSE A FIRE .HAZARD AND WILL VOID ALL WARRANTY CLAIMS.

WARING:THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

SPECIFCATIONS

Product description: Die –cast aluminum outdoor lighting fixture.

Power source: 120V AC 60 Hz

Load rating: 2x 150W Max.

WHAT’S INCLUDED:

A-Gasket 1PC B-Mounting screws 2PCS.

PRE-INSTALLATION GUIDELINES

- 1.A qualified electrician is recommended for installation and wiring .
- 2.Before beginning installation, disconnect the power to the location where the light will be installed by shutting off the circuit breaker or removing the fuse box. .shutting off a wall switch that controls the light is not sufficient to prevent electrical shock.

INSTALLING AND WIRING

1. Pull the supply wires from the house.
2. Place Gasket(A) over the outlet box and pull wires through this gasket.
3. connect the wires using the wire connectors as follows:
 - a. White light fixture wire to White house wire.
 - b. Black light fixture to Black house wire.
4. Secure the light fixture to the outlet box using the 2PCS mounting screws(B)
5. Adjust the socket directions to enjoy the lights by turning the screw rings

IMPORTANT: Apply a weatherproof silicone caulk or sealant around the fixture base.

